


### Early Warning Media Enable/Disable

**Setting Early Warning:** Press the right or left black oval key to display other choices.

This parameter enables the printer to provide early warnings when labels or ribbons are running low or when the printhead needs to be cleaned.



**Default:** Disabled

**Selections:** Disabled, Enabled

To enable the Early Warning System, press **SETUP/EXIT**, then press **NEXT/SAVE**. To select the Early Warning setting, scroll back until Media Enabled is listed on the LCD and press **NEXT/SAVE** to access the media settings. Use the right or left black oval key to select the setting, then press **SETUP/EXIT** and **NEXT/SAVE** to save the setting. Repeat this process to set the early warning for ribbon or maintenance (printhead cleaning).

**NOTE:** When setting the early warning for maintenance, an additional setting appears after the media setting that prompts the LCD to ask **HEAD CLEAN**. Use the right black oval key to select **YES** and then press **SETUP/EXIT** and **NEXT/SAVE** to reset the label counter.

When the printer detects it is running low with less than 15% of the remaining labels or ribbons, the following message appears on the LCD: **WARNING MEDIA LOW** or **WARNING RIBBON LOW**. If the alert function has been enabled, an alert is also sent. When the printhead is opened and then closed after a media or ribbon warning has been received, the LCD asks **MEDIA REPLACED** or **RIBBON REPLACED**. Press the right black oval key **YES** to clear the warning and reset the label counter.

**NOTES:** Labels per roll and ribbon length need to be updated when beginning use of the Early Warning System. The printer does not make any adjustments when power is turned off (O) and on (I).

**If media is disabled, LABELS PER ROLL and RIBBON LENGTH will not be displayed.**

Press the **NEXT/SAVE** key to display **LABELS PER ROLL**.

### Selecting Labels Per Roll

Press the right or left black oval key to display other choices.

This parameter needs to be updated when setting the Early Warning System so the printer can provide early warnings when labels are running low.



**Default:** 900 labels


**Selections:** 100 labels–9999 labels

Press the **NEXT/SAVE** key to display **RIBBON LENGTH**.

### Selecting Ribbon Length

Press the **RIGHT** or **LEFT BLACK OVAL** key to display other choices.

This parameter needs to be updated when setting the Early Warning System so the printer can provide early warnings when ribbon is running low.




**Default:** -450 m (1476 ft.)

**Selections:** 100 m–450 m (328 ft.–1476 ft.)

Press the **NEXT/SAVE** key to display **EARLY WARNING MAINTENANCE**.

### Selecting Early Warning Maintenance On/Off

This parameter tells the printer whether the Early Warning Maintenance is On or Off. If the Early Warning Maintenance is On, the Head Cleaning warning is enabled.



**Default:** Maint. Off

**Selections:** Maintenance On, Maint. Off

**NOTE:** HEAD CLEANING *be displayed only when MAINTENANCE ON is displayed.*

Press the **NEXT/SAVE** key to display the **HEAD CLEANING**.